



DRIVER CHECKLIST

ONCE YOU ARE READY TO LOAD YOUR TRAILER:

1. MAKE SURE TRAILER BLOW DOWN VALVE IS OPEN
2. MAKE SURE TANK AIR PRESSURE GAUGES READ ZERO
3. OPEN AUTO LID CONTROL BOX
4. PULL VALVE WITH BLACK KNOB TO THE RIGHT
5. VISUALLY CONFIRM THAT LID IS OPEN
6. CLOSE CONTROL BOX DOOR
7. START THE LOADING PROCESS

WHEN LOADING IS COMPLETE:

1. VERIFY THERE ARE NO OBSTRUCTIONS TO AUTO LID
2. OPEN CONTROL BOX DOOR
3. PUSH THE VALVE WITH BLACK KNOB TO THE LEFT
4. VISUALLY CONFIRM THAT LID IS CLOSED
5. MAKE SURE LID AIR GAUGE REACHES A MINIMUM OF 80 PSI
6. CLOSE CONTROL BOX DOOR

WHEN OFFLOADING PRODUCT:

1. OPEN CONTROL BOX
2. MAKE SURE LID AIR PRESSURE GAUGE IS AT OR ABOVE 80 PSI
3. MAKE SURE CONTROL BOX DOOR IS CLOSED DURING OFFLOADING

IF YOU HAVE ANY ISSUES WITH LID OPERATION
PLEASE CONTACT YOUR TERMINAL MANAGER
IMMEDIATELY!